



Procedure to Activate GPS Display & Logging on a Bird SiteHawk

(Serial Numbers 4006 and higher only)


1. Using the supplied USB Thumbdrive, insert into a PC and copy the following two files on to it:
 - a. SiteHawk_V1.61.apk
 - b. SKOption_1.0.apk




2. Power on the SiteHawk. After the interface boots, close the application (app):




3. Insert the USB drive from Step 1 into the SiteHawk using the supplied USB 3.0 adaptor. Open the file browser app (Files):




4. Navigate to **Local** -> **General USB drive**:




5. Select SKOption_V1.0, and INSTALL:



6. Select OPEN




7. When the app opens, the “ON/OFF” icon in the upper right is on
YOU MUST TOGGLE THE “SWITCH” OFF THEN ON!




Close the app.


8. Install SiteHawk_V1.61:



9. Select DONE after installation is complete (do not OPEN):




10. Eject the USB Drive and unplug from the SiteHawk by "Swiping" down from the top and selecting "Eject" or selecting "General USB drive" then "Settings" from upper right, followed by "Eject":




The SiteHawk Antenna and Cable Analyzer App will start automatically

11. Turn the GPS location on by “swiping” down from the top of the screen



12. Turn the GPS display ON in the SiteHawk interface:



13. GPS location is now active in the upper left. If a GPS fix is not achieved, the Lon and Lat will display null values (zero)

